

Step 1:

Remove both nuts, washers and the seal



Step 2:

Step 2:

Unwind the 17mm nut so that it sits approx 5mm from the top of the antenna stud



Needed:

- 17mm spanner
- 19mm spanner
- A few drill bits 2/3/5/7 mm
- Drill

Step 3:

Put the 19mm nut on the antenna stud and tighten it against the smaller 17mm nut



Step 4:

Now loosen the antenna stud using the 17mm spanner and finally the antenna itself will slide out.



Step 5:

Use a small drill 2 / 3mm and carefully drill through the center. Flip it around and use a 5mm drill and gently remove excess plastic followed by a 7mm drill to achieve the same result as the other side. Be careful as not to damage the thread!



Step 6:

Clean up the thread and make sure all excess plastic is removed ready to assemble.



Step 7:

Assemble by reversing step 4 to 1

