

KARMANN GHIA DASH INSTALLATION

1958 - 1967

NOTE: Various versions existed, such as; No grill holes, With holes, With large hole, Some with vents, and others without vents.

This dash pad was designed and built to accommodate any, and all configurations.

1.0 OLD DASH REMOVAL

1.1 Remove air vents, if any exist.

1.2 Remove two end screws.

1.3 Prey or peel off old dash completely.

2.0 INSTALLATION OF NEW DASH

2.1 Clean metal exposed surface of any build-up of old glue or residue.

2.2 Install dash when the air temperature is 70° F. The material is flexible and more workable when warm. It will install easily and precisely.

2.3 Replace vents and end screws.

2.4 Raise center portion and apply a contact cement. (obtainable at most hardware stores), to both underside of dash and metal surface.

2.5 Allow glue to dry. (tackfree) and press dash down on metal frame.

2.6 Your installation is now complete.

3.0 To ensure luster and preservation of your new dash, use of Armoral or equivalent is recommended.