



Instructions for P/N: 1455

These clips will allow you to convert your pre 68 sedan or off-road chassis from the swing axle transmission design to I.R.S. suspension.

These are for stock VW, I.R.S. trailing arms and do not apply to long travel (3x3) applications. We recommend that a qualified chassis fabricator do the installation.

For installations without a fixture you should install the stock I.R.S. arms that you intend to use on the car. Attach P/N: 3455 clips to the arms and mock them up for fit on the torsion tube.

Since the years vary you will need to clearance the inside edges of the clips to fit against the horns of the transmission mount. The outer edge of the clip will be approximately 23 mm from the inside edge of the back of the torsion plate housing. When the clips are in place you should have the clips with a 10° angle downward to allow for proper travel before tack welding in place.

Remove the trailing arm from the clips and weld in place.