

Thermostat Installation Instructions

1. Install hose barbs in the (4) threaded ports in the body of the oil stat.

Oil should flow as follows:

- A. From engine to E1 port (marked on oil stat body).
 - B. From the port marked C1 on the oil stat to the cooler.
 - C. From the cooler to C2 port.
 - D. And then the E2 port back into the engine.
2. After installation is complete, start engine and check for leaks.

