

## **Deluxe Aluminum Side Step for VW Type 2 Split Screen and Bay window (Not for the Brazilian Bay)**

- 1. Thank you very much for purchasing our Deluxe Aluminum Side Step for VW Type 2 Split screen and Bay window (Not for the Brazilian Bay).**
- 2. Our Side step is designed to fit in the T2 original Jacking pints. (If the jacking points on your van have been replaced before, you may require adjusting the aluminum brackets. Details are mentioned below)**
- 3. Connect the 2 aluminum end brackets to the step bar (using provided inner square bolts and nuts x 4). Please make sure the radius top corner of the step bar is facing away from the vehicle. Please do not tighten all bolts until it is fitted on the van.**
- 4. Insert the rough ends of the 2 aluminum end brackets to the jacking points under your van. If you cannot insert them or fully insert them, you will need to file the aluminum material on 4 sides of the rough end of the aluminum end brackets until they are in.**
- 5. Use the provided M8 bolts x 2 to fasten the brackets by screwing them from the holes underneath of the jacking points. The holes will be in line with the thread holes built in the bracket. You may need to adjust the position of the brackets slightly to allow the bolts going in.**
- 6. To the replaced jacking points, you will need to drill a M9 hole on each jacking point by measuring the distance from the end brackets to allow that 2 holes are inline.**
- 7. Fasten all bolts. Please do not over tighten them as this is an aluminum side step.**
- 8. Job Done!**