



## **MOUNTING INSTRUCTIONS**

APPLICATION: ADAPTS 1968- 4 LUG LATE VW  
TO 5 LUG 4 3/4" CHEVY BOLTCIRCLE WHEELS

1. Jack vehicle up and install-jack stands under body.
2. Remove wheels.
3. Install offset stud bolt in any of the four lug bolt holes.
4. Screw the offset stud in as far as it will-go by hand.
5. Then unscrew the offset stud until the long end is closest to the axle. Do not unscrew more than one full turn.
6. Place the adapter over the offset stud and install the 3 hex head bolts. Be sure the adapter is flush with the drum all the way around. The 3 bolts should all be able to be tightened by hand. If bolts do not turn freely, twist the offset stud slightly until all the bolts turn freely.
7. Tighten the 3 bolts using a 9/16" socket, as you would a standard lug nut.
8. Install wheel onto adapter using the proper 7/16-20 lug nuts and tighten
9. Be sure all lug nuts are tightened properly, jack vehicle up, remove jack stands
10. For safety reasons only, -check lug nuts every 5000 miles or 8000 km