



INSTALLATION INSTRUCTIONS FOR

1968 - 1977 VW DASH PADS

1. INSIDE CAR

- A. PULL OFF AIR VENT KNOBS.**
- B. REMOVE LIGHTS, WIPERS, AND EMERGENCY KNOBS (TWIST OFF COUNTER-CLOCKWISE).**
- C. REMOVE TWO TOP SHEET METAL SCREWS WITH A #1 PHILLIPS HEAD SCREWDRIVER.**
- D. REMOVE THE BRAKE LIGHT (WARNING LIGHT) SLIPS INSIDE FRONT TRUNK.**

2. INSIDE TRUNK

- A. UNBOLT THE RADIO.**
- B. LOOSEN SPEEDOMETER WITH A 3/4 TURN. TWIST OFF.**
- C. TWIST TABS STRAIGHT ON SPEAKER GRILLS AND THEN PUSH THEM OUT.**
- D. REMOVE THE 4-10MM NUTS (BOTTOM & TOP).**
- E. REMOVE THE 18MM SCREW HOLDING THE GLOVE BOX.**
- F. REMOVE THE FRESH AIR BOX (10MM NUT).**
- G. REMOVE HEATER VENTS AND HOSES.**

3. REVERSE THE ORDER FOR NEW DASH PAD INSTALLATION