

TYPE-3 PADDED DASH INSTALLATION

1.0 OLD DASH REMOVAL

- 1.1 REMOVAL OF HANDLE IF REQUIRED.**
- 1.2 REMOVAL OF ANY EXTERIOR HARDWARE IS REQUIRED.**
- 1.3 CLEAN METAL FRAME AREA.**

2.0 NEW DASH INSTALLATION

- 2.1 INSTALL DASH WHEN AIR TEMPERATURE IS ABOVE 70 F. THE MATERIAL IS FLEXIBLE AND MORE WORKABLE WHEN WARM. IT WILL INSTALL EASILY AND PRECISELY.**
- 2.2 PLACE DASH OVER METAL FRAME AND INSTALL HANDLE FIRST.**
- 2.3 STRETCH DASH TOWARDS DRIVER DOOR AND FIT OVER GAUGE AREA.**
- 2.4 REPLACE ANY AND ALL EXTERIOR HARDWARE AND YOUR INSTALLATION IS COMPLETE.**

TO ENSURE LUSTER AND LONG LIFE, USE OF ARMORAL OR EQUIVALENT IS RECOMMENDED.