

Front Bumper Brackets



With these special brackets you can install pre 67 bumper blades to post 68 models without body modifications.

3822 for pre 66 front fenders (picture above)

It's necessary to drill two additional holes in the bumper, so you will have three instead of two visible bolts on each side of the additional bolts are included with the brackets.

To make drilling easier you can use the template below.

For a better fit of the bracket inside the blade, we suggest using the reinforcements-plates (Paruzzi # 0020 steel or # 9920 stainless steel) These were also used on stock bumper brackets pre 67.

www.paruzzi.com
info@paruzzi.com

