



## Fitting Instructions for Paruzzi VW Hammock for VW T25

Part number: # 70576

Included in the box:

*1x hammock canvas, 2x brackets, 4x spacer washers*

*4x 2cm length screws, 4x 1.5 cm length screws*

*2x male hammock bars*

*2x female hammock bars*

### How to fit the hammock

Please note that the Paruzzi VW hammock bars will fit the original VW Westfalia bay window support brackets without any modification. If fitting to a Westfalia the holes may have been predrilled ready for the installation of a hammock.

The hammock bars are telescopic and therefore can be placed at any height desired. Please note the canvas when installed should be drum tight and sufficient room should be left below the bars, so that when a child is placed in the bed there is sufficient room to clear the steering wheel and the top of the dashboard. Placing the hammock too high may restrict the area in which a child may sleep.

### Step 1:

Mark and drill the holes for the brackets on the A pillar (windscreen side surround). The bracket must be installed at angle.

See photo (Front Bracket at Right Hand side A pillar)



Repeat the procedure on the other A pillar.

**Step 2:** Attach the brackets to the A pillar. On the lower drilled hole place the spacer between the A pillar and the bracket attach the bracket using the longer 2cm length screw provided. The 1.5 cm screw is for the top hole in the bracket. Repeat the procedure on the other A pillar.

**Step3:** Mark and drill the holes for the B pillar bracket.

The brackets must be installed at angle.

See photo (Rear Bracket at Right Hand side B pillar)



**Step 4:** Attach the bracket and spacer using the 2 cm screw to hold the spacer in place. Repeat the bracket installation on the other B pillar. Check all screws are tight.

### **First time Hammock assembly**

**Step 1:** Unfold your new canvas and place on a flat surface.

**Step 2:** Slide the male hammock support bar inside the female hammock support bar. Repeat this process with the other two bars.

**Step 3:** Slide each hammock support bar through the canvas. Make sure the hooked ends face inwards to the middle of the canvas.

**Step4:** Roll up the canvas with the hammock bars threaded through the canvas.

### **Attaching the hammock to the brackets.**

Remove the headrests (if fitted).

Attach the hammock support bar to the brackets on the A pillar (wind screen surround). Unroll the canvas and attach the hammock support bar to the B pillar.

### **Handy tips**

If there is built in furniture present near the bracket attach that side first.

Pull the seat belts slightly forward as they may obstruct.

Check the security of the hammock to brackets before placing an object on the canvas!

New style bracket A pillar



New style bracket B pillar

