


## Installation instruction for seat belt retractor

### WARNING!


The sole function of this device is to allow for seat belt retraction while the belt is **NOT** in use.




Wind 8 times in the direction of the arrow on winder. Do not wind in reverse direction or more than 8 revolutions.



Slip belt through retractor. Take note of the direction of center spring tension. The center winder has been wound counter clockwise



Slip belt under tabs before releasing center winder.



The final result.

## Montageanleitung für Sicherheitsgurtaufroller

### WARNUNG!


Die Funktion des Aufrollers. Ist nur zulässig wenn der Gurt nicht angelegt  
Bei Benutzung des Gurtes muss der komplett ausgerollt




Das Federelement max. 8 Umdrehungen in Pfeilrichtung drehen. Nicht mehr als 8 Umdrehungen! Nicht gegen Pfeilrichtung drehen



Den Gurt durch den Aufroller führen. Achten Sie auf die Richtung des Federelements.



Den Gurt unter die Laschen führen und das Federelement loslassen.



Fertige Ansicht